

Shanklin® A-27A Spare Parts

Shanklin® customers who operate an A-27A system should carry the following spare parts on-site at all times. Readily available spare parts and timely preventative maintenance procedures can reduce downtime, improve efficiency, and increase the lifespan of your Shanklin® system. Spare parts can be ordered individually or as a kit.

A-27A Kit Info

Part #	Description	Quantity
A7049H	A-27A Spare Parts Kit	1
A-27A Kit Com	ponents	
Part #	Description	Quantity
BD-0084	BELT, TIMING 3/4"W*187T	1
BD-0122	BELT, RIBBED V	2
BD-0129	BELT, TIMING 3/4"W*210T	1
EA-0071	RELAY, 24VDC 4-POLE	1
EA-0091	RELAY, 24VDC, 2 POLE	1
EF-0045	FUSE, 20A 600V	2
EF-0201	FUSE, 250V	1
EJ-0009	RELAY, SOLID STATE, 230V 25A DC	1
EJ-0028A	POTENTIOMETER, 10K	1
EJ-0014KIT	TEMPERATURE CONTROL KIT	1
EP-0004	SENSOR, PROXIMITY	2
ET-0010	BLOCK W/DIODE, TERMINAL	1
RU-0052	RUBBER, SILICONE 1/4*7/8*36	2
RU-0055	RUBBER, SILICONE 1/4*7/8*24"	2
SPA-0180-001	HEATER, CARTRIDGE, 240V/840W, 34-1/8"	1
SPA-0230-003	PROBE, THERMOCOUPLE, 96" LG	1
SPA-0273-001	HEATER, CARTRIDGE, 600W, 1/4"OD*24-1/8"	1
F05-1512-001	BLADE, ONE PIECE, SEAL (OLEFIN) A-27	1
F05-0969-004	JAW, CROSS, SEAL, A27 W.FIN	1
F05-0970-002	JAW, FRONT SEAL, WIDE FIN, A-27, S24	1

Contact Shanklin® Customer Experience with the model and serial number of your equipment to verify that the kit you order is in compliance with your Shanklin® system. Different models of the same Shanklin® system can require slightly different parts.

Shanklin® Customer Experience is available to answer questions, provide quotes for spare parts, and place orders. Email shanklinparts@sealedair.com or call (866) 997-7273.